

# Laboratory Procedures



M.Yigit KESKIN

2015

## INDEX

Our Contacts for Supplies

### General Analyses

Analyses for Wine Laboratory  
Chemical Preparation and  
Standardization  
Grape Processing Procedure  
AgCode Entry Procedure  
Measurement of pH  
Titratable Acidity: Colorimetric Method  
Titratable Acidity: Wine Buffer Method  
Volatile Acidity by Cash Still  
Free SO<sub>2</sub> by Aeration-Oxidation  
Total SO<sub>2</sub> by Ripper  
SO<sub>2</sub> addition calculations  
Measurement of turbidity  
Measurement of CO<sub>2</sub> by Carbodoseur  
Measurement of Dissolved Oxygen (D.O.)  
Measurement of Alcohol by Ebulliometer  
Enzymatic Analyses  
L-Malic Acid  
Glucose and Fructose  
Acetic Acid

### Trials

Copper Sulfate Fining Trials  
Heat Stability and Bentonite Bench Trials  
Cold Stability Test

### Bottling

Bottling Timeline  
Bottling Analyses  
Bottling Arrangements  
Hygiena EnSure Software Quick Guide  
Bottling QC sheet  
Bottling Specifications and Tolerances  
Silver Oak Cork QC program

**Annex**

Conversion Reference  
Vine to Wine Conversions

